

D

- Angaben auf Versorgungseinheit beachten.
- Netzanschluss muss bauseitig gemäß der geforderten Schutzart und Schutzklasse vorhanden sein.
-  **Netzanschluss darf nur von Elektrofachkräften durchgeführt werden.** Örtliche Vorschriften beachten.
- Anschlussleitungen nicht über Versorgungseinheit führen.
- Versorgungseinheit nicht mit Wärmedämm-Material abdecken.
- Leuchtmittelwechsel nur im stromlosen Zustand der Leuchte durchführen.
- Bei Leuchtmittelwechsel oder eventuellen Störungen (defektes Leuchtmittel, Übertemperatur, usw.) Neustart/Reset von EVG durchführen. EVG einige Sekunden vom Netz trennen.

GB

Consider the information on the ballast.

Mains connection must be provided on-site according the required protection type and class.

 **Mains Connection must only be done by electricians.**
Consider local regulations.

Do not lead the connecting lines across the ballast.

Do not cover ballast with warmth insulation material.



Do relamping only in the dead state of the luminaire.

ECG Reset: Electronic ballasts (ECG) disconnect automatically with missing or damaged lamp, over-temperature, a.s.o. After that you must disconnect the ECG from the mains for about some seconds, before you can restart it.