



**D**

- Angaben auf Versorgungseinheit beachten.
- Netzanschluss muss bauseitig gemäß der geforderten Schutzart und Schutzklasse vorhanden sein.
-  Netzanschluss darf nur von Elektrofachkräften durchgeführt werden. Örtliche Vorschriften beachten.
- Anschlussleitungen nicht über Versorgungseinheit führen.
- Versorgungseinheit nicht mit Wärmedämm-Material abdecken.
- Leuchtmittelwechsel nur im stromlosen Zustand der Leuchte durchführen.
- Bei Leuchtmittelwechsel oder eventuellen Störungen (defektes Leuchtmittel, Übertemperatur, usw.) Neustart/Reset von EVG durchführen. EVG einige Sekunden vom Netz trennen.

**GB**

*Consider the information on the ballast.*

*Mains connection must be provided on-site according the required protection type and class.*

 **Mains Connection must only be done by electricians.**  
*Consider local regulations.*

*Do not lead the connecting lines across the ballast.*

*Do not cover ballast with warmth insulation material.*



*Do relamping only in the dead state of the luminaire.*

*ECG Reset: Electronic ballasts (ECG) disconnect automatically with missing or damaged lamp, over-temperature, a.s.o. After that you must disconnect the ECG from the mains for about some seconds, before you can restart it.*